




Physics ATP Analysis By Vasumitra Gajbhiye

GENERAL

1. **Why take 5 readings and divide by 5 instead of 1 reading** → timing errors due to human reaction time have less effect./ reduce effect of errors in starting/stopping stopwatch.
2. **How to obtain more reliable readings** → repeat and average. In every seven or six marker do not forget to write this!
3. **When you want to suggest the relationship between two quantities and want to justify them** → within limits of experimental accuracy

Tip for seven/six markers → Do not forget to write plot a graph whenever possible and repeat and take average. Repeat for at least 6 values. Always write units when drawing the tables

7. **How to answer "explain how to use the readings to reach the conclusion" in seven/six markers** →
 - Compare readings in the table to see if change in factor(dependent variable) produces change in (Variable you are measuring, ex - speed, temperature)
 - plot line graph (with axes specified)
8. **How to accurately measure the volume of liquid in a measuring cylinder** →
 - Bottom of the meniscus
 - Line of sight perpendicular to the scale.



9. How to measure diameter of a rod →

- Use of rod between two blocks and measure gap in at least 2 places and take average
- Use micrometre , vernier callipers, measure several points and take average

10. **Precautions while measuring volume of wooden rod** → Wood might absorb water, measuring cylinder scale not precise

11. **How to calculate gradient of graph from a graph** → draw a triangle as large as possible of the graph. Then use the values and calculate the gradient

12. **Why it is useful to take a trial reading for a experiment** → to check if t(dependent variable) is measurable. to check if d(independent variable) value is appropriate. Establish range of d and t values.

LOAD & SCALE

1. **How to ensure if scale is horizontal** → measure distance of rule from bench at two ends and adjust until equal. Horizontal if equal


2. **It is sometimes difficult to position the load on the scale of the metre rule at the correct distance d from the pivot. Suggest one change to the apparatus to overcome this difficulty** → mark centre line of mass, suspend the load from loop of thread and then align with mark on rule

- suspend load from loop of thread
- (measure width of block and) add $\frac{1}{2}$ width to 5.0 cm to find position for edge of block
- mean value of marks at both edges of mass

- mark centre line of mass and align with mark on rule

14. How to make sure the length, l of the pendulum bob is as accurate as possible →


- Measure the top of the bob then add on half diameter measured with blocks and rule or callipers.
- Measure the top and bottom of bob and average
- View perpendicular to the scale
- Rule parallel with string. Use of set-square
- Keep the rule close to the pendulum
- Measure from bottom of the clamp



4. Explain briefly why the position of the pivot may not be exactly at the 50.0 cm mark of the rule → center of mass of ruler not at the center

5. What is the source of inaccuracy in this experiment →

test load not exactly 1.0 N /
spring extension not linear /
metre rule not uniform



TEMPERATURE

1. How to get temperature reading from a thermometer as accurate as possible

→

- Line of sight perpendicular to the thermometer scale. Wait until reading stop rising.
- Stir before reading.
- **IF container present then** - don't let thermometer touch the bottom/sides of the glass beaker/container
- Wait for temperature to reach max before reading.
- IF comparing the temperature of some liquid in two identical beakers - keep the thermometer at same depth

2. What are the control variable while measure the rate of cooling/heating of water in a beaker →

- Same volume of water
- Same initial temperature
- Same surface area of container
- Same diameter and height of container
- Same room temperature
- Same material of beaker
- Same duration of experiment

16. How to reduce loss of thermal energy from beaker →

- insulation
- lid
- lower starting temperature
- higher room temperature
- smaller volume of water
- smaller surface area

17. **Experiment for how lid affects the rate of cooling** → Repeat same experiment without a lid. calculate cooling rate and subtract cooling rate with lid.

RAY TRACE


1. **Possibility errors in ray trace experiments** →
 - Ray has finite thickness, rays not thin
 - Difficulty to align pins.
 - Pins too thick
 - Inaccuracies have more effect on smaller angles
2. **What are the precautions in ray trace experiments** →
 - Use thin pencil lines/ thin pins
 - View bases of pins
 - Large pin separation
 - Ensure pins are vertical/ upright/ erect
22. **Precautions for ray trace experiment** →
 - use thin pin
 - use thin lines OR sharp pencil
 - view bottom of pins OR keep pins upright
 - ensure pins far apart
23. **Why 2.7cm pin separation is not suitable** → pin separation should be as large as possible **for greater accuracy** / much larger / pin separation is too small /

ELECTRICITY

1. **What are the possible difficulties in resistance wire experiments** →
 - Difficulties to judge position of crocodile clips

- Difficult to measure wire to nearest mm
- Contact between wire and crocodile clip not precise
- Difficult to interpolate readings on meters between marks


3 A student is investigating a resistance wire. She uses the circuit shown in Fig. 3.1.



- If u replace a resistance wire with a variable resistor, place the variable resistor in **series** with the circuit.
- What are the disadvantage of NOT using a variable resistor** →
 - cannot obtain continuous set of value.
 - less straightforward to change current
 - more difficult to obtain a greater number of values

LENS

15. Precautions in lens experiments →



- Darkened room/ brighter lamp/ no other lights
- Moving screen slowly to obtain best image
- Mark block to show centre of lens
- Place rule on bench/clamp rule
- Lens and object and screen vertical/perpendicular to the bench
- Repeat measurements/experiment and average